



www.johnsonhardware.com

INSTRUCTIONS

2081 PDF GLASS DOOR GUIDE SET

FOR USE WITH JOHNSON
2000, 2060
POCKET DOOR FRAMES

ATTACH 2081 Guide to floor bracket located at edge of front pocket opening. Use tall guide if Frame Floor Bracket is attached to the sub-floor or the short guide when it is attached to finished floor.

